



## Dear Customer

### ◆ About the Upgrade of the DMC-G3 Firmware

The following functions were added or changed from Ver.1.1 of the firmware.  
Please read this in conjunction with the operating instructions for the camera.

- The firmware version can be checked from the [VERSION DISP.] of the [SETUP] menu.

**[POWER ZOOM LENS] has been added to [CUSTOM] menu.**

<b>[POWER ZOOM LENS]</b>	<p>This may only be selected when using a lens that is compatible with power zoom (electrically operated zoom). (For compatible lenses, please refer to our website)</p>	
	<p><b>[DISP FOCAL LENGTH]:</b> When you zoom, the focal distance is displayed and you can confirm the zoom position.</p> <p>Ⓐ Current focal distance</p> <p><b>[OFF]/[ON]</b></p>	<p><b>[e.g.: When the interchangeable lens (H-PS45175) is used]</b></p> 
	<p><b>[STEP ZOOM]:</b> When you operate the zoom with this setting [ON], the zoom will stop at positions corresponding to predetermined distances.</p> <ul style="list-style-type: none"> <li>• [STEP ZOOM] is disabled during motion picture recording.</li> </ul> <p><b>[OFF]/[ON]</b></p>	<p><b>[e.g.: When the interchangeable lens (H-PS45175) is used]</b></p> 
	<p><b>[ZOOM RESUME]:</b> When you switch the power switch [ON], the zoom positions when you last switched [OFF] are automatically restored.</p> <p><b>[OFF]/[ON]</b></p>	
	<p><b>[ZOOM SPEED]:</b> You can set the zoom speed for zoom lever operations.</p> <ul style="list-style-type: none"> <li>• If you set [STEP ZOOM] to [ON], the zoom speed will not change.</li> </ul> <p><b>[PHOTO]:</b> [H] (High speed), [M] (Middle speed), [L] (Low speed)</p> <p><b>[VIDEO]:</b> [H] (High speed), [M] (Middle speed), [L] (Low speed)</p>	
	<p><b>[ZOOM RING]:</b> This may only be selected when a power zoom-compatible lens with a zoom lever and zoom ring is attached. When set to [OFF], the operations controlled by the zoom ring are disabled to prevent accidental operation.</p> <p><b>[OFF]/[ON]</b></p>	