



Dear Customer

◆ About the Upgrade of the DMC-GF3, DMC-GF2 Firmware

The following functions were added or changed from Ver.1.1 of the firmware.
Please read this in conjunction with the operating instructions for the camera.

- The firmware version can be checked from the [VERSION DISP.] of the [SETUP] menu.

[POWER ZOOM LENS] has been added to [CUSTOM] menu.

[POWER ZOOM LENS]	<p>This may only be selected when using a lens that is compatible with power zoom (electrically operated zoom). (For compatible lenses, please refer to our website)</p>	
	<p>[DISP FOCAL LENGTH]: When you zoom, the focal distance is displayed and you can confirm the zoom position.</p> <p>Ⓐ Current focal distance</p> <p>[OFF]/[ON]</p>	<p>[e.g.: When the interchangeable lens (H-PS14042) is used]</p> 
	<p>[STEP ZOOM]: When you operate the zoom with this setting [ON], the zoom will stop at positions corresponding to predetermined distances.</p> <ul style="list-style-type: none"> • [STEP ZOOM] is disabled during motion picture recording. <p>[OFF]/[ON]</p>	<p>[e.g.: When the interchangeable lens (H-PS14042) is used]</p> 
	<p>[ZOOM RESUME]: When you switch the power switch [ON], the zoom positions when you last switched [OFF] are automatically restored.</p> <p>[OFF]/[ON]</p>	
	<p>[ZOOM SPEED]: You can set the zoom speed for zoom lever operations.</p> <ul style="list-style-type: none"> • If you set [STEP ZOOM] to [ON], the zoom speed will not change. <p>[PHOTO]: [H] (High speed), [M] (Middle speed), [L] (Low speed)</p> <p>[VIDEO]: [H] (High speed), [M] (Middle speed), [L] (Low speed)</p>	
	<p>[ZOOM RING]: This may only be selected when a power zoom-compatible lens with a zoom lever and zoom ring is attached. When set to [OFF], the operations controlled by the zoom ring are disabled to prevent accidental operation.</p> <p>[OFF]/[ON]</p>	