

## Dear Customer

### ◆ About the Upgrade of the DMC-GF6 Firmware


The following functions were added or changed from Ver. 1.2 of the firmware.



Please read this in conjunction with the owner's manual for the camera.

- The firmware version can be checked from the [Version Disp.] of the [Setup] menu.



### Manual focus operation is now available for the interchangeable lens with no focus ring (H-FS12032).

When using the interchangeable lens with no focus ring (H-FS12032)

- 1 Set the [Focus Mode] in the [Rec] menu to [MF].
- 2 Press ◀ (  ).
- 3 Press ▲/▼/◀/▶ to move the MF area, and press [MENU/SET].
  - Pressing [DISP.] will return the MF area back to the center.
- 4 Press ◀/▶ to focus.
  - (A) Slide bar
  - (B) MF Assist (enlarged screen)
    - Pressing and holding ◀/▶ will increase the focus speed.
    - Focus can also be adjusted by dragging the slide bar.
    - The MF area setting screen can be displayed by pressing ▼.



- When the interchangeable lens with no focus ring (H-FS12032) is used, the [MF Assist] settings in the [Custom] menu change as follows:

[ON]	Focus can be adjusted when ◀(  ) is pressed and the MF area setting screen is displayed.
[OFF]	Focus can be adjusted when ◀(  ) is pressed. The MF area setting screen will not be displayed.

### [Lens w/o Focus Ring] has been added to the [Custom] menu.

- This item is available only when the interchangeable lens with no focus ring (H-FS12032) is used.

[Lens w/o Focus Ring]	<b>[MF Magnification Level]:</b> You can set the initial magnification level of MF Assist from 4×, 5×, or 10×. [4.0×]/[5.0×]/[10.0×]
	<b>[Control Dial (MF)]:</b>
	<b>[MAGLEVEL]:</b> Rotating the control dial allows you to change the magnification level of the enlarged area. <b>[FOCUS]:</b> Rotating the control dial allows you to adjust the focus.