



<b>Create a Firmware Update CD</b>	
<p><b>1.</b> Double-click on the file you downloaded. It is a self-extracting ".exe" file.</p> <p>Copy the firmware update file (the file that ends in ".ROM") to a folder on your hard drive. The file name and size may vary from the example shown here.</p> <p>Do Not rename or modify the file in any way. Doing so may cause it to be loaded improperly, resulting in an inoperative or unresponsive DVD player theater.</p>	
<p><b>2.</b> Place the mouse cursor on the firmware file ending in ".ROM" and "right click." Select "send to", and then select the CD-R writing device installed in your PC.</p> <p>If "send to" does not appear as an option, enable "CD Writing" in the XP control panel.</p>	
<p><b>3.</b> Windows XP will display a notice in the lower portion of the screen alerting you that you have files waiting to be written to a CD-R.</p> <p>Click on the box. Click on the box when it appears.</p>	
<p><b>4.</b> Select "Write These Files to CD."</p> <p>That's it. In just a few minutes the CD-R will be created and you'll be ready to install the firmware into your Panasonic DVD player theater.</p>	
<p><b>5.</b> Please proceed to the "Install the firmware update".</p>	