

## Dear Customer

### ◆ About the Upgrade of the DMC-G6 Firmware



The following functions were added or changed from Ver. 1.2 of the firmware.  
Please read this in conjunction with the owner's manual for the camera.

- The firmware version can be checked from the [Version Disp.] of the [Setup] menu.

**Manual focus operation is now available for the interchangeable lens with no focus ring (H-FS12032).**

When using the interchangeable lens with no focus ring (H-FS12032)

- 1 Set the [Focus Mode] in the [Rec] menu to [MF].
- 2 Press  $\blacktriangleleft$  ( $\square$ ).
  - 3 Press  $\blacktriangledown/\blacktriangleright/\blacktriangleleft/\blacktriangleright$  to move the MF area, and press [MENU/SET].
    - Pressing [DISP.] will return the MF area back to the center.
  - 4 Press  $\blacktriangleright/\blacktriangleleft$  to focus.
    - (A) Slide bar
    - (B) MF Assist (enlarged screen)
      - Pressing and holding  $\blacktriangleleft/\blacktriangleright$  will increase the focus speed.
      - Focus can also be adjusted by dragging the slide bar.
      - The MF area setting screen can be displayed by pressing  $\blacktriangledown$ .



- When the interchangeable lens with no focus ring (H-FS12032) is used, the [MF Assist] settings in the [Custom] menu change as follows:

[ON]	Focus can be adjusted when $\blacktriangleleft$ ( $\square$ ) is pressed and the MF area setting screen is displayed.
[OFF]	Focus can be adjusted when $\blacktriangleleft$ ( $\square$ ) is pressed. The MF area setting screen will not be displayed.