

Dear Customer

◆ About the Upgrade of the DMC-GH1 Firmware

The following functions were added or changed from Ver.1.1 of the firmware.

Please read this in conjunction with the operating instructions for the camera.

- The firmware version can be checked from the [VERSION DISP.] of the [SETUP] menu.

Burst speed is now faster.*

* Only when the [BURST RATE] in the [REC] mode menu is set to [H].

When the version of the firmware is Ver.1.0



Burst speed: 3 pictures/second (High speed)

When the version of the firmware is Ver.1.1 or later

Burst speed: 3.5 pictures/second (High speed)

Shutter speed can be set slower than 1/30 sec. (up to 1/2 sec.) now in the Creative Motion Picture mode [CM].*

* Only when the [EXPOSURE MODE] in the [MOTION PICTURE] mode menu is set to [M], and the focus mode dial set to [MF].

- It cannot be set slower than 1/30 sec. when the [REC MODE] in the [MOTION PICTURE] mode menu is set to [AVCHD] ([]), and [REC QUALITY] is set to [FHD] ([]).