



Owner's Manual Manuel d'utilisation

CFexpress Card Carte CFexpress

Model No./N° de modèle **RP-CFEX128/
RP-CFEX256**



THE FOLLOWING APPLIES ONLY IN THE U.S.A. / CE QUI S'APPLIQUE QU'AUX ÉTATS-UNIS.

FCC Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution:

Any unauthorized changes or modifications to this equipment would void the user's authority to operate this device.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Suppliers Declaration of Conformity

Trade Name: Panasonic

Model No.: RP-CFEX128 / RP-CFEX256

Responsible Party:

Panasonic Corporation of North America

Two Riverfront Plaza, Newark, NJ 07102-5490

Support Contact:

<http://shop.panasonic.com/support>

THE FOLLOWING APPLIES ONLY IN CANADA. / CE QUI S'APPLIQUE QU'AU CANADA.

CAN ICES-3(B)/NMB-3(B)

Thank you for purchasing this product.

- Please read these instructions carefully before using this product, and save this manual for future use.

Supplied accessory:	CFexpress card case (1)
----------------------------	-------------------------

READ THIS FIRST

You may be prompted to format the card when it is used with equipment not compatible with the CFexpress card. Doing so will result in loss of data, so be sure to cancel.

A About this CFexpress card

This CFexpress card can only be used with CFexpress compatible equipment. Before using this card, please confirm that your equipment is compatible with CFexpress cards.

- This card has been formatted already, but refer to the operating instructions of the CFexpress-compatible equipment before using it.

B How to check CFexpress compatible equipment

Check the presence of the CFexpress logo, or refer to the operating instructions of the equipment or the information supplied by the manufacturer.

When the CFexpress card is inserted into equipment not compatible with CFexpress cards

- A message saying that "Re-insert the card", "This card cannot be used", etc., may display.
- A message saying "This card needs to be formatted", etc., or a format screen may display.
 - Do not format the card as problems with compatibility will occur if you format it in incompatible equipment.
- The power may not go on.

When the CFexpress card is used on equipment not compatible with CFexpress cards

- Note that it may cause a problem with the compatibility of the card or data may be lost.

C Precautions

■ WARNING

Cease use immediately in the event of abnormalities or malfunctions

- **Whenever any smoke, odd odor, unusual noise is detected**
- **When liquid or foreign objects got inside**
- **When damaged**
- **When abnormally hot**

Fire or electrocution may result if you continue use.

- Cease use and consult your dealer.

Do not disassemble or modify

Burns or fire may result if the card malfunctions or metal objects get into it.

Do not put metal objects into the card or allow liquids such as water to get onto it

Fire or electrocution may result due to shorting and overheating.

- Do not place receptacles containing liquids such as water or metal objects near or above this product.
- Be particularly careful when there are children around.

Do not touch this product with wet hands or use it in wet areas

The card may malfunction or fire or electrocution may result.

- Do not use the product in locations that have a lot of water, humidity, steam, dust, or oily smoke such as a bathroom.

■ CAUTION

Do not place in locations such as the following where temperatures can get very high:

- **In locations exposed to direct sunlight**
In particular, temperatures in mid-summer vehicle cabins and trunks can become unimaginably high (approximately 60 °C (140 °F) or more). Never leave this product in such areas.
- **In locations subject to strong magnetic fields or static electricity**
- **In locations where the humidity exceeds the usage environment stipulated in the operating instructions for this product, or where condensation occurs**
- **In very dusty locations**
- **Near flames or where hot air collects**
- **In places where there is a danger of current leakage or water leakage**

The card may malfunction or fire or electrocution may result.

- This can also cause deterioration of the casing and internal parts, so care should be taken.

Take care of high temperatures when removing from the device

In particular, the metal surfaces can become hot. Check as you remove it.

Do not touch the product directly for long periods

Directly touching the hot parts of the product over long periods can be the cause of low temperature burns*.

- * People with poor blood circulation (people with vascular disorders, defective circulation, diabetes, or receiving intense pressure) or people with sensitive skin are prone to low-temperature burns.

Keep out of reach of children

Danger of swallowing.

- If swallowed, seek medical advice immediately.

D Specifications

Capacity indicated on the card:

128 GB (RP-CFEX128)
256 GB (RP-CFEX256)

Card type:

CFexpress Ver.2.0 TypeB

Interface:

PCIe Gen3 x2

Protocol:

NVMe1.3

Data transfer speed:

Maximum read out speed: 1700 MB/s
Maximum write speed: 1000 MB/s

Default formatting type:

exFAT

Operating temperature:

−10 °C to 70 °C (14 °F to 158 °F)

Operating humidity:

5 %RH to 95 %RH (no condensation)

Operating voltage:

3.3 V

Storage temperature:

−40 °C to 85 °C (−40 °F to 185 °F)

Dimensions (Width×Length×Thickness):

38.5 mm×29.6 mm×3.8 mm
(1.52"×1.17"×0.15")

Mass (Weight):

Approx. 8 g (0.28 oz)

- Specifications are subject to change without notice.

E When using or storing the card

- Different devices have different formatting requirements. When reformatting the card, format according to the operating instructions of the device. All of the data stored on the CFexpress card is deleted when it is formatted. Before formatting, save any necessary data to your computer, etc.
- Do not disassemble, alter, apply strong shocks, bend, drop or wet with water. These can cause the card to malfunction. Furthermore, do not touch the metal terminals with your hands or metals.
- Do not peel off the labels that are attached or attach new labels or stickers.
- The device may not be able to function properly, so do not use where it can be subjected to the effects of static electricity or electronic noise. If the device stops working properly, switch the device off, remove the card from the device, then insert the card again.
- After using the card, put it back into the supplied card case for storage.
- Do not leave in locations that may become hot such as in cars or exposed to direct sunlight. Do not leave in locations with high humidity, where there is a lot of dust, or where corrosive gases, etc., may occur.
- Under no circumstances should this product be used in applications where special quality or reliability is a requirement, where malfunction or erroneous operation can directly threaten human life or cause harm to people, or for specialist applications (for aeronautical or astronautical purposes, for transportation devices, for combustion devices, for life-supporting devices, for safety apparatuses, etc.).


F Protecting your data

- Do not remove the card, or turn off devices or peripheral devices in which the card is inserted while the CFexpress card is working (data is being read or written). Do not remove the batteries from battery-operated equipment. These actions can cause data to be destroyed.
- We recommend backing up important data. Panasonic will not accept responsibility for any data loss, or loss directly or indirectly caused by data loss.

■ About writing on this card

The space for writing on the card can be directly written on using an oil-based pen, etc.


(Rear)



- Do not use excessive force as it may damage the card. Take care not to stain the metal terminals.

G Identifying the week and year of production

(Rear)



Week and year of production (the numbers are examples)

1910

a b

a Year of production

19: 2019

20: 2020

⋮

b Week of production

01: Week 1 of the year of production

02: Week 2 of the year of production

⋮

H Cautions about disposal or transferring ownership of this card

CFexpress compatible equipment may contain the functions "Format" and "Erase". However, in most cases all data on the card will not be completely erased even after performing these functions. Be aware of this when transferring the card to another person.

When you dispose of the CFexpress card, destroy it physically and follow your local rules of separation and disposal of waste.

The data recorded to the CFexpress card is protected by copyright laws and, apart from personal use, may not be used without the permission of the rights holder.

Panasonic takes no responsibility for any loss or direct or indirect failure that might occur to the data recorded on the CFexpress card.

The CFexpress logo is a trademark licensed by the CompactFlash Association.

Nous vous remercions d'avoir arrêté votre choix sur cet appareil.

- Avant d'utiliser l'appareil, il est recommandé de lire attentivement ce manuel et de le conserver pour utilisation ultérieure.

Accessoire fourni : CFexpress étui à carte (1)

IMPORTANT

Il est possible que l'on vous invite à formater la carte lorsque la carte CFexpress est utilisée avec un appareil non compatible. Cette action aura comme conséquence la suppression des données. Il est donc essentiel d'annuler cette opération.

A À propos de cette carte CFexpress

Cette CFexpress carte ne peut être utilisée qu'avec un appareil compatible CFexpress. S'assurer de la compatibilité de l'équipement avec la carte CFexpress avant toute utilisation de celle-ci.

- Cette carte est préformatée. Consulter les instructions d'opération de l'équipement compatible avant d'utiliser la carte CFexpress.

B Comment vérifier la compatibilité de l'appareil avec la carte CFexpress

Il suffit de confirmer la présence du logo CFexpress ou de consulter le mode d'emploi fourni par le fabricant pour l'appareil.

Quand la carte CFexpress est insérée dans un appareil qui n'est pas compatible avec les cartes CFexpress

- Un message comme « Réinsérer la carte », « Cette carte ne peut pas être utilisée », etc. pourrait apparaître.
- Un message comme « Cette carte doit être formatée », etc., ou un écran de formatage pourrait apparaître.
→ Ne pas formater cette carte puisque des problèmes de compatibilité se produiront si celle-ci est formatée dans un appareil non compatible.
- L'appareil pourrait ne pas se mettre en marche.

Quand la carte CFexpress est utilisée dans un appareil qui n'est pas compatible avec les cartes CFexpress

- Il est à noter que cela peut causer un problème avec la compatibilité de la carte ou les données risquent d'être perdues.

C Précautions

■ AVERTISSEMENT

Cesser immédiatement l'utilisation en cas d'anomalies ou de mauvais fonctionnement

- Si de la fumée, des odeurs bizarres, des bruits inhabituels sont détectés
- Si des liquides ou des corps étrangers sont entrés à l'intérieur de l'appareil
- Si l'appareil est endommagé
- Si l'appareil est anormalement chaud

L'utilisation d'un appareil dans ces conditions peut provoquer un feu ou une électrocution.

- Cesser l'emploi et consulter le revendeur.

Ne pas démonter ni modifier

Cela pourrait causer un feu ou une électrocution si la carte fonctionne mal ou si des objets métalliques s'y trouvent.

Ne pas placer d'objet métallique dans la carte ou laisser des liquides comme de l'eau entrer en contact avec celle-ci

Cela pourrait causer un feu ou une électrocution en raison d'un court-circuit et de surchauffe.

- Ne pas utiliser le récipient contenant un liquide, comme de l'eau, ou des objets métalliques à proximité ou au-dessus de ce produit.
- Il faut faire preuve d'une plus grande vigilance lorsqu'il y a des enfants à proximité.

Ne pas toucher ce produit avec des mains mouillées et ne pas l'utiliser dans des endroits humides

La carte pourrait mal fonctionner et un feu ou une électrocution pourrait en résulter.

- Ne pas utiliser le produit dans des endroits où il y a beaucoup d'eau, d'humidité, de vapeur, de poussière ou de fumée huileuse, comme une salle de bain.

■ ATTENTION

Ne pas placer dans des endroits comme ceux cités plus bas où les températures peuvent être très élevées :

- **Dans les endroits exposés à la lumière directe du soleil**
En particulier, les habitacles et les coffres des véhicules au milieu de l'été peuvent atteindre des températures très chaudes (environ 60 °C (140 °F) ou plus). Ne jamais laisser ce produit dans de tels endroits.
- **Dans des emplacements exposés à de forts champs magnétiques ou à de l'électricité statique**
- **Dans les endroits où l'humidité dépasse l'environnement d'utilisation stipulé dans le mode d'emploi de ce produit, ou dans les endroits où de la condensation se produit**
- **Dans des endroits très poussiéreux**
- **Près des flammes et là où l'air chaud peut s'accumuler**
- **Dans les endroits où il y a un risque de fuite de courant ou d'eau**

La carte pourrait mal fonctionner et un feu ou une électrocution pourrait en résulter.

- Cela peut également entraîner une détérioration du boîtier et des pièces internes, il faut donc faire preuve de prudence.

Faire attention à la température élevée de la carte lorsqu'elle est retirée de l'appareil

Les surfaces métalliques peuvent plus particulièrement devenir chaudes. Vérifier si tel est le cas lorsque la carte est retirée de l'appareil.

Ne pas toucher le produit directement trop longtemps

Le contact direct avec les parties chaudes du produit sur de longues périodes peut être la cause de brûlures à basse température*.

- * Les personnes ayant une mauvaise circulation sanguine (personnes souffrant de troubles vasculaires, de troubles de la circulation, de diabète, ou recevant une pression intense) ou dont la peau est sensible sont sujettes aux brûlures à basse température.

Garder hors de portée des enfants

Danger d'avalement.

- En cas d'avalement, chercher immédiatement un service d'urgence.

D Données techniques

Capacité de mémoire indiquée sur la carte :

128 Go (RP-CFEX128)

256 Go (RP-CFEX256)

Type de carte :

CFexpress Ver.2.0 TypeB

Interface :

PCIe Gen3 x2

Protocole :

NVMe1.3

Vitesse de transfert des données :

Vitesse maximale de lecture : 1 700 Mo/s

Vitesse maximale d'écriture : 1 000 Mo/s

Type de formatage par défaut :

exFAT

Température de fonctionnement :

−10 °C à 70 °C (14 °F à 158 °F)

Humidité de service :

5 % à 95 % (pas de condensation)

Tension de fonctionnement :

3,3 V

Température d'entreposage :

−40 °C à 85 °C (−40 °F à 185 °F)

Dimensions (LargeurXLongueurXEpaisseur) :

38,5 mm×29,6 mm×3,8 mm

(1,52 po×1,17 po×0,15 po)

Poids :

Environ 8 g (0,28 oz)

- Sujet à changements sans préavis.

E Lors de l'utilisation ou du rangement de la carte

- Les appareils différents ont des exigences différentes de formatage. Lors du reformatage de la carte, formater conformément au mode d'emploi de l'appareil. Toutes les données stockées sur la carte CFexpress sont effacées lorsqu'elle est formatée. Avant le formatage, sauvegarder toutes les données nécessaires sur votre ordinateur, etc.
- Ne pas démonter, modifier, soumettre à de forts chocs, plier, faire tomber ou mouiller la carte avec de l'eau. Cela pourrait entraîner un dysfonctionnement de la carte. Ne pas toucher ses bornes métalliques avec les mains ou des objets métalliques.
- Ne pas décoller les étiquettes qui sont attachées ou apposer de nouvelles étiquettes ou autocollants.
- Ne pas utiliser cette carte dans un endroit sujet aux effets de l'électricité statique ou des parasites électriques, l'appareil hôte pouvant ne pas fonctionner correctement. Si l'appareil hôte ne fonctionne pas correctement, éteindre ce dernier, en retirer la carte, puis la réinsérer.
- Après avoir utilisé la carte, la remettre dans son étui fourni pour la ranger.
- Ne pas laisser dans des endroits qui peuvent devenir chauds comme dans les véhicules ou exposés à la lumière directe du soleil. Ne pas laisser dans des endroits où l'humidité est élevée, où il y a beaucoup de poussière ou où des gaz corrosifs, etc. peuvent se former.
- Ce produit ne doit en aucun cas être utilisé dans le cadre d'applications où une qualité ou une fiabilité particulière est exigée, où un dysfonctionnement ou un fonctionnement erroné peut directement menacer la vie humaine ou causer des dommages aux personnes, ou pour des applications spécialisées (à des fins aéronautiques ou astronautiques, pour des appareils de transport, de combustion, de survie, de sécurité, etc.).


F Protection des données

- Ne pas retirer la carte et ne pas mettre hors tension les appareils ou périphériques dans lesquels la carte CFexpress est insérée pendant son fonctionnement (les données étant en lecture ou en écriture). Ne pas retirer les piles des appareils alimentés par pile. Ces actions peuvent entraîner la destruction des données.
- Il est recommandé de sauvegarder les données importantes. Panasonic décline toute responsabilité en cas de perte de données ou de perte directement ou indirectement causée par une perte de données.

■ À propos de l'écriture sur cette carte

L'espace d'écriture sur la carte peut être écrit directement à l'aide d'un stylo à huile, etc.


(Arrière)



- Ne forcez pas trop en écrivant car cela pourrait endommager la carte. Prenez soin de ne pas salir les contacts métalliques.

G Identification de la semaine et de l'année de production

(Arrière)



La semaine et l'année de production (les chiffres sont indiqués à titre d'exemple)

1910

a b

a Année de production

19: 2019

20: 2020

⋮

b Semaine de production

01: Semaine 1 de l'année de production

02: Semaine 2 de l'année de production

⋮

H Mises en garde lors de la mise au rebut ou du transfert de propriété de cette carte

Les appareils compatibles avec la norme CFexpress peuvent offrir des fonctions « Formater » et « Effacer ». Cependant, dans la plupart des cas, les données de la carte ne seront pas complètement effacées, même après l'exécution de ces opérations. Ce fait doit être pris en compte lorsque la carte est transférée à une autre personne. Lorsque la carte CFexpress est mise au rebut, la détruire physiquement. Les règles locales en matière de recyclage et d'élimination des déchets doivent être respectées.

Les données enregistrées sur la carte CFexpress sont protégées par les lois sur le droit d'auteur et, à l'exception d'une utilisation personnelle, ne peuvent être utilisées sans l'autorisation du titulaire des droits.

Panasonic décline toute responsabilité en cas de perte ou de défaillance directe ou indirecte des données enregistrées sur la carte CFexpress.

Le logo CFexpress est une marque déposée sous licence de la CompactFlash Association.

ONLY FOR U.S.A.

Panasonic Products Limited Warranty

Limited Warranty Coverage

If your product does not work properly because of a defect in materials or workmanship, Panasonic Corporation of North America (referred to as "the warrantor") will, for the length of the period indicated on the chart below, which starts with the date of original purchase ("warranty period"), at its option either (a) repair your product with new or refurbished parts, (b) replace it with a new or a refurbished equivalent value product, or (c) refund your purchase price. The decision to repair, replace or refund will be made by the warrantor.

Product or Part Name	Parts	Labor
CFexpress Card (in exchange for defective item)	90 days	Not Applicable

During the "Labor" warranty period there will be no charge for labor. During the "Parts" warranty period, there will be no charge for parts. This Limited Warranty excludes both parts and labor for non-rechargeable batteries, antennas, and cosmetic parts (cabinet). This warranty only applies to products purchased and serviced in the United States. This warranty is extended only to the original purchaser of a new product which was not sold "as is".

Mail-In Service—Online Repair Request

Online Repair Request

To submit a new repair request and for quick repair status visit our Web Site at <http://shop.panasonic.com/support>

When shipping the unit, carefully pack, include all supplied accessories listed in the Owner's Manual, and send it prepaid, adequately insured and packed well in a carton box. When shipping Lithium Ion batteries please visit our Web Site at <http://shop.panasonic.com/support> as Panasonic is committed to providing the most up to date information. Include a letter detailing the complaint, a return address and provide a daytime phone number where you can be reached. A valid registered receipt is required under the Limited Warranty.

IF REPAIR IS NEEDED DURING THE WARRANTY PERIOD, THE PURCHASER WILL BE REQUIRED TO FURNISH A SALES RECEIPT/PROOF OF PURCHASE INDICATING DATE OF PURCHASE, AMOUNT PAID AND PLACE OF PURCHASE. CUSTOMER WILL BE CHARGED FOR THE REPAIR OF ANY UNIT RECEIVED WITHOUT SUCH PROOF OF PURCHASE.

Limited Warranty Limits and Exclusions

This warranty ONLY COVERS failures due to defects in materials or workmanship, and DOES NOT COVER normal wear and tear or cosmetic damage. The warranty ALSO DOES NOT COVER damages which occurred in shipment, or failures which are caused by products not supplied by the warrantor, or failures which result from accidents, misuse, abuse, neglect, mishandling, misapplication, alteration, faulty installation, set-up adjustments, misadjustment of consumer controls, improper maintenance, power line surge, lightning damage, modification, introduction of sand, humidity or liquids, commercial use such as hotel, office, restaurant, or other business or rental use of the product, or service by anyone other than a Factory Service Center or other Authorized Servicer, or damage that is attributable to acts of God.

THERE ARE NO EXPRESS WARRANTIES EXCEPT AS LISTED UNDER "LIMITED WARRANTY COVERAGE". THE WARRANTOR IS NOT LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY.

(As examples, this excludes damages for lost time, travel to and from the servicer, loss of or damage to media or images, data or other memory or recorded content. The items listed are not exclusive, but for illustration only.)

ALL EXPRESS AND IMPLIED WARRANTIES, INCLUDING THE WARRANTY OF MERCHANTABILITY, ARE LIMITED TO THE PERIOD OF THE LIMITED WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the exclusions may not apply to you.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state. If a problem with this product develops during or after the warranty period, you may contact your dealer or Service Center. If the problem is not handled to your satisfaction, then write to:

Consumer Affairs Department
Panasonic Corporation of North America
661 Independence Pkwy
Chesapeake, VA 23320

PARTS AND SERVICE, WHICH ARE NOT COVERED BY THIS LIMITED WARRANTY, ARE YOUR RESPONSIBILITY.

Shop Accessories!

for all your Panasonic gear

Go to

<http://shop.panasonic.com/support>

Get everything you need to get the most out of
your Panasonic products

Accessories & Parts for your Camera, Phone, A/V
products, TV, Computers & Networking, Personal
Care, Home Appliances, Headphones, Batteries,
Backup Chargers & more...

Customer Services Directory

For Product Information, Operating Assistance,
Parts, Owner's Manuals, Dealer and Service info
go to <http://shop.panasonic.com/support>

For the hearing or speech impaired TTY: 1- 877-833-8855

As of April 2017

FOR CANADA

Panasonic Canada Inc.

5770 Ambler Drive, Mississauga, Ontario L4W 2T3

PANASONIC PRODUCT – LIMITED WARRANTY

EXCHANGE PROGRAM

Panasonic Canada Inc. warrants this product to be free from defects in material and workmanship under normal use and for a period as stated below from the date of original purchase agrees to, at its option either (a) repair your product with new or refurbished parts, (b) replace it with a new or a refurbished equivalent value product, or (c) refund your purchase price. The decision to repair, replace or refund will be made by Panasonic Canada Inc.

CFexpress Card

Ninety (90) days

This warranty is given only to the original purchaser, or the person for whom it was purchased as a gift, of a Panasonic brand product mentioned above sold by an authorized Panasonic dealer in Canada and purchased and used in Canada, which product was not sold "as is", and which product was delivered to you in new condition in the original packaging.

IN ORDER TO BE ELIGIBLE TO RECEIVE WARRANTY SERVICE HEREUNDER, A PURCHASE RECEIPT OR OTHER PROOF OF DATE OF ORIGINAL PURCHASE, SHOWING AMOUNT PAID AND PLACE OF PURCHASE IS REQUIRED

LIMITATIONS AND EXCLUSIONS

This warranty ONLY COVERS failures due to defects in materials or workmanship, and DOES NOT COVER normal wear and tear or cosmetic damage. The warranty ALSO DOES NOT COVER damages which occurred in shipment, or failures which are caused by products not supplied by Panasonic Canada Inc., or failures which result from accidents, misuse, abuse, neglect, mishandling, misapplication, alteration, faulty installation, set-up adjustments, misadjustment of consumer controls, improper maintenance, power line surge, lightning damage, modification, introduction of sand, humidity or liquids, commercial use such as hotel, office, restaurant, or other business or rental use of the product, or service by anyone other than a Authorized Servicer, or damage that is attributable to acts of God.

Dry cell batteries are also excluded from coverage under this warranty.

THIS EXPRESS, LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT WILL PANASONIC CANADA INC. BE LIABLE FOR ANY SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY. (As examples, this warranty excludes damages for lost time, travel to and from the Authorized Servicer, loss of or damage to media or images, data or other memory or recorded content. This list of items is not exhaustive, but for illustration only.)

In certain instances, some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, or the exclusion of implied warranties, so the above limitations and exclusions may not be applicable. This warranty gives you specific legal rights and you may have other rights which vary depending on your province or territory.

CONTACT INFORMATION

For product operation and information assistance, please visit our Support page:
www.panasonic.ca/english/support

For defective product exchange within the warranty period, please contact the original dealer.

The serial number of this product is the 7-digit number found on the back of the CFexpress card that contains the year and week of production. Please note them in the space provided below and keep for future reference.

MODEL NUMBER _____ RP-CFEX128/RP-CFEX256

SERIAL NUMBER _____

User memo:

DATE OF PURCHASE _____

DEALER NAME _____

DEALER ADDRESS _____

TELEPHONE NUMBER _____

POUR LE CANADA

Panasonic Canada Inc.

5770, Ambler Drive, Mississauga (Ontario) L4W 2T3

PRODUIT PANASONIC – GARANTIE LIMITÉE

PROGRAMME DE REMPLACEMENT

Panasonic Canada Inc. garantit que ce produit est exempt de défauts de matériaux et de main-d'œuvre dans un contexte d'utilisation normale pendant la période indiquée ci-après à compter de la date d'achat original et, dans l'éventualité d'une défectuosité, accepte, à sa discrétion, de (a) réparer le produit avec des pièces neuves ou remises à neuf, (b) remplacer le produit par un produit neuf ou remis à neuf d'une valeur équivalente ou (c) rembourser le prix d'achat. La décision de réparer, remplacer ou rembourser appartient à Panasonic Canada Inc.

Carte CFexpress

Quatre-vingt-dix (90) jours

La présente garantie n'est fournie qu'à l'acheteur original d'un des produits de marque Panasonic indiqués plus haut, ou à la personne l'ayant reçu en cadeau, vendu par un détaillant Panasonic agréé au Canada et utilisé au Canada. Le produit ne doit pas avoir été "vendu tel quel" et doit avoir été livré à l'état neuf dans son emballage d'origine.

POUR ÊTRE ADMISSIBLE AUX SERVICES AU TITRE DE LA PRÉSENTE GARANTIE, LA PRÉSENTATION D'UN REÇU D'ACHAT OU DE TOUTE AUTRE PIÈCE JUSTIFICATIVE DE LA DATE D'ACHAT ORIGINAL, INDIQUANT LE MONTANT PAYÉ ET LE LIEU DE L'ACHAT, EST REQUISE.

RESTRICTIONS ET EXCLUSIONS

La présente garantie COUVRE SEULEMENT les défaillances attribuables à un défaut des matériaux ou à un vice de fabrication et NE COUVRE PAS l'usure normale ni les dommages esthétiques. La présente garantie NE COUVRE PAS NON PLUS les dommages subis pendant le transport, les défaillances causées par des produits non fournis par Panasonic Canada Inc., ni celles résultant d'un accident, d'un usage abusif ou impropre, de négligence, d'une manutention inadéquate, d'une mauvaise application, d'une altération, d'une installation ou de réglages incorrects, d'un mauvais réglage des contrôles de l'utilisateur, d'un mauvais entretien, d'une surtension temporaire, de la foudre, d'une modification, de la pénétration de sable, de liquides ou d'humidité, d'une utilisation commerciale (dans un hôtel, un bureau, un restaurant ou tout autre usage par affaires ou en location), d'une réparation effectuée par une entité autre qu'un centre de service Panasonic agréé ou encore d'une catastrophe naturelle.

Les piles sèches sont également exclues de la présente garantie.

CETTE GARANTIE LIMITÉE ET EXPRESSE REMPLACE TOUTE AUTRE GARANTIE, EXPRESSE OU IMPLICITE, INCLUANT LES GARANTIES IMPLICITES DU CARACTÈRE ADEQUAT POUR LA COMMERCIALISATION ET UN USAGE PARTICULIER. PANASONIC CANADA INC. N'AURA D'OBLIGATION EN AUCUNE CIRCONSTANCE POUR TOUT DOMMAGE DIRECT, INDIRECT OU CONSÉCUTIF RÉSULTANT DE L'UTILISATION DE CE PRODUIT OU DÉCOULANT DE TOUTE DÉROGATION À UNE GARANTIE EXPRESSE OU IMPLICITE. (À titre d'exemples, cette garantie exclut les dommages relatifs à une perte de temps, le transport jusqu'à et depuis un centre de service agréé, la perte ou la détérioration de supports ou d'images, de données ou de tout autre contenu en mémoire ou enregistré. Cette liste n'est pas exhaustive et n'est fournie qu'à des fins explicatives.)

Certaines juridictions ne reconnaissent pas les exclusions ou limitations de dommages indirects ou consécutifs, ou les exclusions de garanties implicites. Dans de tels cas, les limitations stipulées ci-dessus peuvent ne pas être applicables. La présente garantie vous confère des droits précis; vous pourriez aussi avoir d'autres droits pouvant varier selon votre province ou territoire de résidence.

DEMANDE DE RENSEIGNEMENTS

Pour tout renseignement sur les produits et de l'assistance technique, veuillez visiter notre page Soutien :
www.panasonic.ca/french/support

Pour le remplacement d'un produit défectueux couvert par la garantie, veuillez communiquer avec le revendeur d'origine.

Le numéro de série de ce produit est le numéro de 7 chiffres qui se trouve au dos de la carte CFexpress et qui contient l'année et la semaine de production. Veuillez le noter dans l'espace fourni ci-dessous, et conserver le tout pour référence future.

NUMÉRO DE MODÈLE _____ RP-CFEX128/RP-CFEX256

NUMÉRO DE SÉRIE _____

Homologation :

DATE D'ACHAT _____

DÉTAILLANT _____

ADRESSE DU DÉTAILLANT _____

N° DE TÉLÉPHONE _____

Panasonic Corporation of North America
Two Riverfront Plaza, Newark, NJ 07102-5490
<http://shop.panasonic.com>

Panasonic Canada Inc.
5770 Ambler Drive, Mississauga, Ontario, L4W 2T3
www.panasonic.com

